

28B700

Illustrated Parts List

Model Series

28B700

TYPE NUMBERS
0001 through 1201.

For Use On Engines Built Before Date Code – 02033100

TABLE OF CONTENTS

Air Cleaner	4
Alternator	8
Blower Housing/Shrouds	7
Cams	2
Carburetor	3
Controls	5
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder	2
Electric Starter	9
Flywheel	6
Fuel Tank	5
Governor Spring	5
Head	2
Ignition	8
Kits/Gaskets–Carburetor	3
Kits/Gaskets–Valve	2
Muffler	4
Oil	2
Piston Group	2
Rewind	6
Valves	2


PRINTED IN U.S.A.

BRIGGS & STRATTON




COPYRIGHT © BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

28B700









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 0153-2 Assemblies include all parts shown in frames. 4C-5/2002

NIKKI





WALBRO




WALBRO








NIKKI






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
0153-4 Assemblies include all parts shown in frames. 4C-5/2002



















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
0153-6 Assemblies include all parts shown in frames. 4C-5/2002








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 0153-7 Assemblies include all parts shown in frames. 4C-5/2002

DC ONLY	DUAL CIRCUIT	TRI CIRCUIT	10 AMP	16 AMP	9AMP
474 	474A 	474B 	474C 	474C 	474B 
578 	878 	878A 	578 	578 	578 
526A 501 				526 501A 	

NOTE: All Stators Use No. 1119 Mounting Screw. 



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



28B700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	496413	Cylinder Assembly	23B	693555	Flywheel (Rewind Start Engines)			696404 Ring Set (.010" Oversize) (Used After Code Date 01060600).
2	399265	Kit-Bushing/Seal (Magneto Side)	24	222698	Key-Flywheel			696405 Ring Set (.020" Oversize) (Used After Code Date 01060600).
3	★391086	Seal-Oil (Magneto Side)	25	696397	Piston Assembly (Standard) (Used After Code Date 01060600).			696406 Ring Set (.030" Oversize) (Used After Code Date 01060600).
4	494238	Sump-Engine		696398	Piston Assembly (.010" Oversize) (Used After Code Date 01060600).			----- Note -----
5	494240	Head-Cylinder		696399	Piston Assembly (.020" Oversize) (Used After Code Date 01060600).			499996 Ring Set (Standard) (Used Before Code Date 01060700).
7	★Ø271866	Gasket-Cylinder Head		696400	Piston Assembly (.030" Oversize) (Used After Code Date 01060600).			392331 Ring Set (Standard Chrome) (Used Before Code Date 01060700).
8	495735	Breather Assembly ----- Note ----- 495734 Breather Assembly Used on Type No(s). 0130, 0139, 1139, 1201.		----- Note -----				499997 Ring Set (.010" Oversize) (Used Before Code Date 01060700).
9	★Ø27803	Gasket-Breather		499284	Piston Assembly (Standard) (Used Before Code Date 01060700).			498998 Ring Set (.020" Oversize) (Used Before Code Date 01060700).
10	691666	Screw (Breather Assembly)		499288	Piston Assembly (.010" Oversize) (Used Before Code Date 01060700).			499999 Ring Set (.030" Oversize) (Used Before Code Date 01060700).
11	692253	Tube-Breather		499292	Piston Assembly (.020" Oversize) (Used Before Code Date 01060700).	27	691299	Lock-Piston Pin (Used After Code Date 95101500).
12	★692226	Gasket-Crankcase (.015" Thick) ----- Note ----- ★692406 Gasket-Crankcase (.005" Thick) ★692405 Gasket-Crankcase (.009" Thick)		499296	Piston Assembly (.030" Oversize) (Used Before Code Date 01060700).			----- Note -----
13	690904	Screw (Cylinder Head)		26	696403			691792 Lock-Piston Pin (Used Before Code Date 95101600).
14	691109	Stud (Cylinder Head)						
15	690946	Plug-Oil Drain						
16	693944	Crankshaft						
20	★291675	Seal-Oil (PTO Side)						
22	692125	Screw (Crankcase Cover/ Sump)						
23	693557	Flywheel (Steel Ring Gear) ----- Note ----- 693556 Flywheel Used on Type No(s). 0123, 0146, 1123, 1125, 1140, 1146, 1166.						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

0153-10

Assemblies include all parts shown in frames.

4C-5/2002

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
28	498319	Pin-Piston (Standard) (Used After Code Date 95101500). ----- Note ----- 299691 Pin-Piston (Standard) (Used Before Code Date 95101600).	51A ★	272554	Gasket-Intake	58	695132	Rope-Starter (.2" Diameter, 59" Long)(Cut To Required Length) (Used After Code Date 99102400). ----- Note ----- 695132 Rope-Starter (.2" Diameter, 59" Long)(Cut To Required Length) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
		498320 Pin-Piston (.005" Oversize) (Used After Code Date 95101500). 391286 Pin-Piston (.005" Oversize) (Used Before Code Date 95101600).	53	690227	Stud (Carburetor)			58A 692188 Rope-Starter (63" Long)(Cut To Required Length) (Used Before Code Date 99102500). ----- Note ----- 692188 Rope-Starter (63" Long)(Cut To Required Length) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
29	494504	Rod-Connecting (Standard) ----- Note ----- 495490 Rod-Connecting (.020" Undersize)	54	690953	Screw (Intake Manifold)			59 490653 Insert-Grip
		495490 Rod-Connecting (.020" Undersize)	55	695130	Housing-Rewind Starter (Used After Code Date 99102400). ----- Note ----- 695130 Housing-Rewind Starter (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	60	490652	Grip-Starter Rope
31	222299	Lock-Rod Screw	55A	393576	Housing-Rewind Starter (Used Before Code Date 99102500). ----- Note ----- 393576 Housing-Rewind Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	63	690547	Spring-Ratchet (Used Before Code Date 99102500). ----- Note ----- 690547 Spring-Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
32	690356	Screw (Connecting Rod) (1 7/8" Long)	56	695129	Pulley-Starter (Used After Code Date 99102400).			64 691920 Adapter-Ratchet Spring (Used Before Code Date 99102500). ----- Note ----- 691920 Adapter-Ratchet Spring (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
32A	690348	Screw (Connecting Rod) (1 5/8" Long)	56A	295871	Pulley-Starter (Includes 63" Long Rope) (Used Before Code Date 99102500). ----- Note ----- 295871 Pulley-Starter (Includes 63" Long Rope) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.			
33	262246	Valve-Exhaust						
34	262247	Valve-Intake						
35	691605	Spring-Valve (Intake)						
36	691597	Spring-Valve (Exhaust)						
37	690456	Guard-Flywheel						
37A	690806	Guard-Flywheel						
40	690656	Retainer-Valve (Intake)						
40A	691939	Retainer-Valve (Exhaust)						
42	494553	Keeper-Valve	57	695131	Spring-Rewind Starter (Used After Code Date 99102400).			
43	691968	Slinger-Governor/Oil						
45	691811	Tappet-Valve	57A	490179	Spring-Rewind Starter (Used Before Code Date 99102500). ----- Note ----- 490179 Spring-Rewind Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.			
46	697668	Camshaft (Used After Code Date 02021700). ----- Note ----- 692123 Camshaft (Used Before Code Date 02021800).						
50	691711	Manifold-Intake						
51	◆692284	Gasket-Intake						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊗ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

28B700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
65	695453	Screw (Rewind Starter) (Used After Code Date 99102400). ----- Note ----- 695453 Screw (Rewind Starter) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.			----- Note ----- 691945 Ratchet-Clutch (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148	111	691679	Pin-Retainer
65A	690837	Screw (Rewind Starter) (Used Before Code Date 99102500). ----- Note ----- 690837 Screw (Rewind Starter) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148	71	691359	Cover-Ratchet (Used Before Code Date 99102500). ----- Note ----- 691359 Cover-Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	121	697884	Kit-Carburetor Overhaul (LMT 696160, 696162, 696164, 696166) ----- Note ----- 497481 Kit-Carburetor Overhaul (LMT 63, 65, 66) 499220 Kit-Carburetor Overhaul (LMT 92, 93, 96, 108, 111, 162, 165, 169) 499231 Kit-Carburetor Overhaul (LMT 97, 99, 133, 135, 136, 166, 168)
66	399671	Clutch-Starter (Used Before Code Date 99102500). ----- Note ----- 399671 Clutch-Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	73	691191	Screen-Rotating	125	697594	Carburetor (LMT 696160, 696162, 696164, 696166) (Gravity Feed) ----- Note ----- 498027 Carburetor (LMT 77, 78, 79, 80, 81, 92, 93, 96, 97, 99, 100, 108, 111, 133, 134, 136, 162, 165) (Gravity Feed) 499163 Carburetor (LMT 166, 167, 168, 169) (Pump Feed)
67	394897	Clutch-Housing (Used Before Code Date 99102500). ----- Note ----- 394897 Clutch-Housing (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	74	691627	Screw (Rotating Screen)	127	●695005	Plug-Welch ----- Note ----- ●694524 Plug-Welch (LMT 696160, 696162, 696164, 696166)
68	691604	Ball-Clutch (Used Before Code Date 99102500). ----- Note ----- 691604 Ball-Clutch (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	74A	691655	Screw (Rotating Screen)	130	690468	Valve-Throttle (LMT 111, 169)
70	691945	Ratchet-Clutch (Used Before Code Date 99102500).	75	690582	Washer (Flywheel)	130A	691750	Valve-Throttle
			76	68238	Seal-Ratchet (Used Before Code Date 99102500). ----- Note ----- 68238 Seal-Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	131	494885	Kit-Throttle Shaft (LMT 111, 169)
			78	690661	Screw (Flywheel Guard)	131A	494379	Kit-Throttle Shaft
			93	●690602	Bushing-Throttle Shaft			
			94	498030	Kit-Idle Mixture			
			94A	496589	Kit-Idle Mixture			
			95	●691636	Screw (Throttle Valve)			
			98	495800	Kit-Idle Speed			
			104	●690525	Pin-Float Hinge			
			105	●231855	Valve-Float Needle			
			106	●690577	Seat-Inlet (Gravity Feed) ----- Note ----- ●691780 Seat-Inlet (Pump Feed)			
			108	690464	Valve-Choke (Manual Choke)			
			108A	692344	Valve-Choke (Choke A Matic)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊗ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

0153-12

Assemblies include all parts shown in frames.

4C-5/2002

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
133	494381	Float–Carburetor			497970 Nozzle– Carburetor (High Altitude) (LMT 97,98)			690480 Spring– Governor Used on Type No(s). 0101, 0102, 0111, 0122, 0126, 0145, 0604, 1016, 1101, 1114, 1142, 1143, 1144.
137	♦♦281165	Gasket–Float Bowl			Key–Timing			691795 Spring– Governor Used on Type No(s). 0139, 0146, 1139, 1146, 1166.
141	495097	Kit–Choke Shaft (Manual Choke)	146	691639	Jet–Pilot (LMT 63, 65, 66, 97, 99, 100, 133, 135, 136)			691798 Spring– Governor Used on Type No(s). 0112, 0123, 0132, 0135, 0610, 0632, 1019, 1025, 1026, 1112, 1114, 1123, 1132, 1135, 1147, 1148, 1152, 1153, 1154, 1155, 1174, 1193.
141A	495931	Kit–Choke Shaft (Choke A Matic)	147	♦497472	----- Note ----- 231983 Jet–Pilot (LMT 136) 498239 Jet–Pilot (LMT 92)			690576 Spring– Governor Used on Type No(s). 0137, 0151, 1172.
142	♦697592	Nozzle–Carburetor (Standard) (LMT 696160, 696162, 696164, 696166) ----- Note ----- ♦496519 Nozzle– Carburetor (Standard) (LMT 63, 65, 66) ♦497568 Nozzle– Carburetor (Standard) (LMT 97, 99, 100) ♦497860 Nozzle– Carburetor (Standard) (LMT 133, 134, 135, 136) ♦498545 Nozzle– Carburetor (Standard) (LMT 108, 111) ♦499037 Nozzle– Carburetor (Standard) (LMT 162, 165, 169) ♦499039 Nozzle– Carburetor (Standard) (LMT 166, 167, 168) ♦691434 Nozzle– Carburetor (Standard) (LMT 92, 93, 94, 96)	165	693148	Nut (Ring Gear)	216	691840	Link–Choke
			167	692297	Seal–Air Cleaner Nut	216A	690574	Link–Choke
			176	★Ø691917	Seal–O Ring (Air Cleaner Base)	216B	691281	Link–Choke
			179	697935	Screw (Fuel Tank Strap)	222	694042	Bracket–Control (Used After Code Date 99010100). ----- Note ----- 691644 Bracket– Control (Used Before Code Date 99011100). 222A 692002 Bracket–Control Used on Type No(s). 0145, 1142.
			182	690443	Bracket–Fuel Tank (Right Hand) ----- Note ----- 222980 Bracket–Fuel Tank (Right Hand) Used on Type No(s). 0135.			
			182A	692535	Bracket–Fuel Tank (Left Hand)			
			183	692960	Strap–Fuel Tank (Right Hand)			
			183A	496852	Strap–Fuel Tank (Left Hand)			
			186	692317	Connector–Hose			
			186A	691609	Connector–Hose			
			187	296004	Line–Fuel (Cut to Required Length)			
			187A	691371	Line–Fuel (Molded)			
			202	691841	Link–Mechanical Governor			
			203	691381	Crank–Bell			
			205	691693	Screw (Bell Crank)			
			209	691278	Spring–Governor ----- Note ----- 692208 Spring– Governor Used on Type No(s). 0113, 0115, 0127, 0128, 0130, 1128, 1160.			
143	499040	Nozzle–Carburetor (High Altitude) (LMT 165, 166, 167) 498258 Nozzle– Carburetor (High Altitude) (LMT 66, 100, 133, 134, 136) 497737 Nozzle– Carburetor (High Altitude) (LMT 92, 93, 96)						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

♦ Included in Carburetor Gasket Set–Ref. No. 977.

Ø Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

28B700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
227	691374	Lever–Governor Control	304	695065	Housing–Blower (Black) (Used After Code Date 99102400). ----- Note -----			497595 Motor–Starter (3 5/8" Housing Length For Plastic Ring Gear Only)
231	●691636	Screw (Choke Valve)						497401 Motor–Starter (4 3/8" Housing Length For Plastic Ring Gear Only)
232	691842	Spring –Governor Link						
237	690409	Retainer–Muffler Guard			695055 Housing–Blower (Red) (Used After Code Date 99102400).			693054 Motor–Starter (3 5/8" Housing Length For Aluminum Ring Gear Only)
240	298090	Fuel Filter ----- Note ----- 394358 Filter–Fuel Used on Type No(s). 0111, 0130.			690846 Housing–Blower (Black) (Used Before Code Date 99102500).			
261	690278	Screw (Control Slide)			691400 Housing–Blower (Red) (Used Before Code Date 99102500).	309A		499521 Motor–Starter (4 3/8" Housing Length For Aluminum Ring Gear Only)
263	690367	Screw (Muffler Guard Retainer)			695065 Housing–Blower (Black) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	309B		499521 Motor–Starter (For Replacement Starter Motor, Order Ref 309)
265	691024	Clamp–Casing						499521 Motor–Starter (For Replacement Starter Motor, Order Ref 309)
267	690804	Screw (Casing Clamp)						
268	691025	Casing –Control Wire (72" Long) (Cut to Required Length) ----- Note ----- 691072 Casing–Control Wire (48" Long) (Cut to Required Length)				310	690323	Bolt (Starter Motor) (3 5/8" Housing Length) ----- Note -----
269	691026	Wire–Control (78" Long) (Cut to Required Length) ----- Note ----- 692589 Wire–Contro (54" Long) (Cut to Required Length)	305	692198	Screw (Blower Housing)			691263 Bolt (Starter Motor) (4 3/8" Housing Length)
270	691027	Nut (Control Wire Casing)	305A	692127	Screw (Blower Housing)			692329 Bolt (Starter Motor) (4 9/16" Housing Length)
271	691028	Lever–Control	306	690459	Shield–Cylinder	311	497608	Brush Set
276	●◆692255	Washer–Sealing	307	691003	Screw (Cylinder Shield)	311A	395538	Brush Set (3 5/8" Housing Length)
287	691002	Screw (Dipstick Tube)	308	491490	Cover–Cylinder Head	311B	490311	Brush Set (4 9/16" Housing Length)
298	691808	Locknut–Muffler/Elbow	309	693551	Motor–Starter (3 5/8" Housing Length For Steel Ring Gear Only) ----- Note -----	322	690960	Screw (Cylinder Head Cover)
300	691874	Muffler			693552 Motor–Starter (4 3/8" Housing Length For Steel Ring Gear Only)	332	690662	Nut (Flywheel)
300A	498984	Muffler				333	492341	Armature–Magneto
300B	391569	Muffler						
301	93768	Pipe–Exhaust						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊗ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

0153–14

Assemblies include all parts shown in frames.

4C–5/2002

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
334	691061	Screw (Magneto Armature)	456	695128	Plate–Pawl Friction (Used After Code Date 99102400). ----- Note ----- 695128 Plate–Pawl Friction (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	505	691251	Nut (Governor Control Lever)
337	802592	Plug–Spark				507	691972	Insulator
344	693675	Screw (Cable Clamp)				510	693699	Drive–Starter (Used With Steel Ring Gear)
346	690661	Screw (Spark Arrester)				510A	497606	Drive–Starter (Used With Aluminum and Plastic Ring Gears)
349	691105	Nut (Cylinder Head Cover) (1 Wire, 16 45/64" Long)	459	281505	Pawl–Ratchet (Used After Code Date 99102400). ----- Note ----- 281505 Pawl–Ratchet (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	510B	495878	Drive–Starter
356	690799	Wire–Stop (1 Wire, 7 11/16" Long)				513	692024	Clutch–Drive
356A	398808	Wire–Stop (2 Wires, 15" and 15 11/16" Long)				520	691084	Terminal–Ground
356B	399222	Wire–Stop				523	692013	Dipstick
356E	692390	Wire–Stop (1 Wire, 17" Long)				524	★281370	Seal–Dipstick Tube
357	691483	Key–Drive Pulley	467	691668	Knob–Air Cleaner	525	690841	Tube–Dipstick
358	494241	Gasket Set–Engine	474	691953	Alternator (DC Only)	526	690326	Screw (Regulator)
359	691077	Washer (Ground Terminal)	474A	691063	Alternator (Dual Circuit)	527	690394	Clamp–Tube
363	19203	Flywheel Puller	474B	691065	Alternator (Tri Circuit)	544	692034	Armature–Starter (3 5/8" Housing Length)
373	691612	Nut (Ground Terminal)	480	690664	Screw (Tube Clamp)	544A	390837	Armature–Starter (For 3 5/8" Housing Length)
383	89838	Wrench–Spark Plug	493	695450	Bracket–Mounting (Used After Code Date 99102400). ----- Note ----- 695450 Bracket–Mounting (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.			----- Note ----- 490309 Armature–Starter (For 4 3/8" Housing Length)
385	692198	Screw (Fuel Pump)				552	491986	Bushing–Governor Crank
387	808656	Pump–Fuel				559	690661	Screw (Remote Choke Stop)
404	691691	Washer (Governor Crank)				562	691119	Bolt (Governor Control Lever)
445	691667	Filter–Air Cleaner Cartridge	493A	692825	Bracket–Mounting (Used Before Code Date 99102500). ----- Note ----- 692825 Bracket–Mounting (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	563	695449	Screw (Debris Screen Guard) (Used After Code Date 99102400). ----- Note ----- 695449 Screw (Debris Screen Guard) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
450	691261	Washer (Fuel Tank Bracket)						
455	695113	Cup–Flywheel (Used After Code Date 99102400). ----- Note ----- 695113 Cup–Flywheel (Used After Code Date 99102400). Used on Type No(s). 1041, 1148.						
455A	691173	Cup–Flywheel (Used Before Code Date 99102500).	501	691188	Regulator			
			503	691532	Strap–Starter			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊗ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

28B700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
563A	690859	Screw (Debris Screen Guard) (Used Before Code Date 99102500). ----- Note ----- 690859 Screw (Debris Screen Guard) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	608	695058	Starter–Rewind (Used After Code Date 99102400). ----- Note ----- 695058 Starter–Rewind (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	668	690510	Spacer
578	692306	Wire Assembly (1 Wire, 46–1/2" Long)(Snap Connect Female Pin Socket, and Bare Wire End)	608A	390391	Starter–Rewind (Used Before Code Date 99102500). ----- Note ----- 390391 Starter–Rewind (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	668A	691323	Spacer
592	690800	Nut (Rewind Starter) (Used Before Code Date 99102500). ----- Note ----- 690800 Nut (Rewind Starter) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	613	691416	Screw (Exhaust Muffler)	674	691105	Screw (Fuel Tank Bracket) (Used On Rewind Starter Engines) ----- Note ----- 690341 Screw (Fuel Tank Bracket) (Used On Electric Starter Engines)
597	691696	Screw (Pawl Friction Plate) (Used After Code Date 99102400). ----- Note ----- 691696 Screw (Pawl Friction Plate) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	613A	690297	Screw (Exhaust Muffler)	676	396903	Deflector–Muffler
601	95162	Clamp–Hose (Green)	613B	692198	Screw (Exhaust Muffler)	676A	393761	Deflector–Muffler
601A	691038	Clamp–Hose (Black)	614	691620	Pin–Cotter	676B	397630	Deflector–Muffler
607	690703	Screw (Air Cleaner Brace)	616	692012	Crank–Governor	677	690661	Screw (Muffler Deflector)
607A	691693	Screw (Air Cleaner Brace)	621	692310	Switch–Stop	678	490817	Spacer–Rewind (Used Before Code Date 99102500). ----- Note ----- 490817 Spacer–Rewind (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
			628	690661	Screw (Fuel Pump Bracket)	687	691949	Slide–Control
			634	●690801	Spring/Seal Assembly (Manual Choke)	688	690395	Cap–Friction
			634A	●690802	Spring/Seal Assembly (Choke A Matic)	689	690529	Spring–Friction
			635	66538	Boot–Spark Plug	689A	691855	Spring–Friction (Used After Code Date 99102400). ----- Note ----- 691855 Spring–Friction (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
			646	690460	Brace–Air Cleaner	691	★692407	Seal–Governor Shaft
			654	690958	Nut (Carburetor)	692	690572	Spring–Detent ----- Note ----- 691301 Spring–Detent Used on Type No(s). LMT 696162, 696166.
			655	691734	Anchor–Rewind Spring (Used Before Code Date 99102500). ----- Note ----- 691734 Anchor–Rewind Spring (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	695	693109	Screw (Ring Gear)

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊗ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

0153–16

Assemblies include all parts shown in frames.

4C–5/2002

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
697	690372	Screw (Drive Cap)	797	693167	Nut (Brush Retainer)	871	261961	Bushing–Valve Guide (Exhaust)
697A	690372	Screw (Drive Cap)	797A	691029	Nut (Brush Retainer)	----- Note -----		
707	690279	Nut (Fuel Tank Strap)	801	691429	Cap–Drive	231218	Bushing–Valve Guide	
709	262243	Eccentric	801A	394856	Cap–Drive	(Intake) (Brass)		
718	690959	Pin–Locating	802	691286	Cap–End	875	693670	Base–Air Cleaner (Plastic)
725	690420	Shield–Heat	802A	395537	Cap–End (3 5/8" Housing Length)	876	495877	Kit–Pinion Spring
725A	690403	Shield–Heat	----- Note -----			877	393456	Wire/Connector– Alternator
726		Gear–Ring (Steel) (Sold In Flywheel Kit, Reference 23, Only)	494988 Cap–End (4 3/8" Housing Length)			877A	393814	Wire/Connector– Alternator
726A	399676	Gear–Ring (Aluminum) (Services Plastic Ring Gear Only)	803	693757	Housing–Starter (3 5/8" Housing Length) (4 3/8" Housing Length, Serviced by Ref. 309)	877B	393537	Wire/Connector– Alternator
727	490324	Cover–Starter Drive	----- Note -----			878	691237	Harness–Alternator (2 Wires, 48–1/2 And 48–1/2" Long)
729	690596	Clip–Wire	803A	398159	Housing–Starter (3 5/8" Housing Length)	878A	691955	Harness–Alternator (3 Wires, 5", 48", and 48" Long)(Snap Connect Pin Socket, 2 Bare Wire Ends, and 2 Insulated Rectifier Diodes)
729A	691224	Clip–Wire	494205 Housing– Starter (4 3/8" Housing Length)			883 ★	692236	Gasket–Exhaust
729B	224723	Clip–Wire	810	691779	Extension–Crankshaft	892	692318	Switch–Key
732	691002	Screw (Starter Drive Cover)	832	692361	Guard–Muffler	896	691641	Pin–Drive Retainer
733	691658	Screw (Crankshaft Extension)	836	691083	Screw (Muffler Guard)	918	393815	Hose–Vacuum (Cut to Required Length)
741	691284	Gear–Timing	842	★691870	Seal–O Ring (Dipstick Tube)	920	691656	Solenoid–Starter
757	691714	Link–Counterweight	846	90832	Washer (Fuel Tank Strap)	930	691904	Guard–Rewind (Used Before Code Date 99102500).
758	692423	Counterweight	847	496367	Dipstick/Tube Assembly	----- Note -----		
759	691239	Pin–Counterweight	851	493880	Terminal–Spark Plug	691904 Guard–Rewind (Used Before Code Date 00022100).		
761	691096	Screw (Counterweight)	869	691802	Seat–Valve (Intake)	Used on Type No(s). 1041, 1148.		
783	693713	Gear–Pinion (For Steel Ring Gear)	870	691844	Seat–Valve (Exhaust)			
783A	693058	Gear–Pinion (For Plastic Ring Gear Only)						
783B	693059	Gear–Pinion (For Aluminum Ring Gear Only)						
788	690458	Bracket–Fuel Pump						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

Ø Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

28B700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
934	690372	Screw (Fan Retainer)	977	494385	Gasket Set–Carburetor			695036 Label–Emissions (Used After Code Date 99093000 and Before Code Date 00070300).
949	695448	Guard–Debris Screen (Used After Code Date 99102400). ----- Note ----- 695448 Guard–Debris Screen (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	987	●691326	Seal–Throttle Shaft (LMT 111, 169)			694325 Label–Emissions (Used After Code Date 99010300 and Before Code Date 99100100).
			990	691959	Key Set			499362 Label–Emissions (Used After Code Date 97063000 and Before Code Date 99010400).
			994	392390	Arrestor–Spark			499361 Label–Emissions (Used Before Code Date 97070100).
			1005	695056	Fan–Flywheel (Used After Code Date 99102400). ----- Note ----- 695056 Fan–Flywheel (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.			1051 691265 Ring–Retaining
949A	397530	Guard–Debris Screen (Used Before Code Date 99102500). ----- Note ----- 397530 Guard–Debris Screen (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	1005A	691905	Fan–Flywheel (Used Before Code Date 99102500). ----- Note ----- 691905 Fan–Flywheel (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	1054	280275	Tie–Cable
						1058	274787	Owner's Manual
950	691657	Screw–Float Bowl				1090	691293	Retainer–Brush
957	493988	Cap–Fuel Tank (Plastic)	1006	690452	Retainer–Fan	1091	691333	Cap–Limiter
958	494768	Valve–Fuel Shut Off (Plastic)	1019	697764	Kit–Label	1095	498539	Gasket Set–Valve
967	272477	Filter–Pre Cleaner	1036	696770	Label–Emissions (Used After Code Date 01093000). ----- Note ----- 695699 Label–Emissions (Used After Code Date 00070200 and Before Code Date 01100100).	1119	691183	Screw (Alternator)
968	691324	Cover–Air Cleaner						
971	692126	Screw (Air Cleaner Base)						
972	390225	Tank–Fuel (Plastic)(3 Quart)						
975	495933	Bowl–Float						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊗ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

0153–18

Assemblies include all parts shown in frames.

4C–5/2002